

Model	JF-U1
Wireless Frequency System	433MHz
Operating Distance	up to 30meters
Receiver includes	1/4"-20 tripod mount
Sync	1/250s
Channel	16 channels
Transmitter power	1x 23A battery
Receiver power	2x AAA battery
Weight	Transmitter: 30g (without battery) Receiver: 42g (without battery)
Dimension	Transmitter: 62.6x39.2x27.1mm Receiver: 79.9x37.8x33.2mm
Components Included	JF-U Transmitter x1 pcs JF-U Receiver x1 pcs Studio Light Cable x1 pcs 3.5mm-6.3mm adapter x1 pcs AAA Alkaline Battery x2 pcs 23A Battery x1 pcs Manual x1 pcs
Material	ABS
Warranty	One year warranty

*Optional Shutter Release Cables for JF-G1P/JF-G2P is available (for the list please refer to Page 29)

JF-T/JF-U/JF-G Flash Trigger Compatible Flashgun Models

Canon	580EX II	580EX	540EZ	520EZ	430EX II
	430EX	430EZ	420EX	420EZ	380EX
Nikon	SB-900	SB-800	SB-600	SB-28	SB-27
	SB-26	SB-25	SB-24	SB-700	
Olympus	FL-50R	FL-50	FL-36R	FL-36	
Pentax	AF-540 FGZ	AF-360 FGZ	AF-400 FT	AF-240 FT	AF-200FG
Sigma	EF-530 DG Super	EF-530 DG ST (for Nikon only)	EF-500 DG Super	EF-500 DG ST (for Nikon only)	EF-430
Vivitar	285HV	283	DF-400MZ	DF-340MZ	
Metz	36AF	48AF	58AF		
Bower	SFD35C/N	SFD728C/N	SFD328C/N/O	SFD680C/N	SFD926OC/N/O
	SFD850				
Phoenix	DZBIS-112CII	SmartFlash 99c/n			

Other flash models with a trigger voltage of 12V or lower

*Optional JJC Shutter Release Cables for JF-U1,U2/JF-G1, G2/JF-G1S, G2S/JF-G1P, G2P

Cable-A	replaces CANON RS-80N3
Cable-B	replaces NIKON MC-30
Cable-C	replaces CANON RS-60E3/PENTAX CS-205
Cable-D	replaces PANASONIC DMW-RLS1
Cable-F	replaces SONY RM-S1AM
Cable-F2	For SONY Cameras with Multi Interface
Cable-G	replaces NIKON MC-DC1
Cable-H	replaces SIGMA CR-11
Cable-I	replaces SIGMA CR-21
Cable-I2	replaces SIGMA CR-31
Cable-J	replaces OLYMPUS RM-UC1
Cable-K	replaces FUJIFILM RR-80
Cable-M	replaces NIKON MC-DC2
Cable-N	replaces SAMSUNG SR2NX02
Cable-O	for FUJIFILM HS50EXR
Cable-S	replaces SONY RM-DR1
Cable-R	replaces FUJIFILM RR-90
Cable-K2O	Convert JJC K plug to O plug
Cable-K2R	Convert JJC K plug to R plug