

## Câbles pour Intervallomètres 1/2

JJC



### Câble-A remplace CANON RS-80N3 / TC-80N3

EOS 1D	EOS-1D C	EOS 1D Mark II	EOS 1D Mark III	EOS 1D Mark IV
EOS-1D Mark II N	EOS 1Ds	EOS 1Ds Mark II	EOS 1Ds Mark III	EOS-1D X
EOS-1D X Mark II	EOS 1V	EOS 3	EOS 5D	EOS 5D Mark II
EOS 5D Mark III	EOS 5D Mark IV	EOS 5DS	EOS 5DS R	EOS 6D
EOS 6D Mark II	EOS 7D	EOS 7D Mark II	EOS 10D	EOS 20D
EOS 20Da	EOS 30D	EOS 40D	EOS 50D	EOS D30
EOS D60	EOS D2000	EOS R5		

### Câble-B remplace NIKON MC-30, 30A, 36

D500	D5	D810	D4s	
D2H	D1x	D1h	D1	D2x
D100	D200	F5	D2Xs	D3
D3s	D3x	D4	D300	D300s
D700	D800	F6	F100	F90
F90x	D850			

### Câble-M remplace NIKON MC-DC2

D90	D600	D610	D750	D3100
D3200	D3300	D5000	D5100	D5200
D5300	D5500	D5600	D7000	D7100
D7200	D7500	Df	P7700	P7800
Z6	Z7 - Z7 II	P1000	Z5	Z6 II